




Engineered Bamboo Flooring



P.A.C.E. Pre-Installation Checklist

Distributed by Bamboo Design & Architecture

1 (844) 293-6060

www.BambooDesignArchitecture.ca

Before you begin installation, remember to P.A.C.E. yourself with the checklist below. Full installation instructions and maintenance guidelines can also be found online at www.bamboodesignarchitecture.ca


PREPARE THE SUBFLOOR



Use Planiseal® VS on concrete

Make sure the subfloor is flat, level, clean and free of debris. New concrete must be cured for at least 60 days. Test the subfloor moisture prior to installation and apply an appropriate moisture barrier such as Planiseal VS on concrete subfloors

ACCLIMATE FLOORING



Acclimate Your Engineered Flooring For 1 to 3 Days

For Engineered flooring, lay boxes on the floor and only open box ends as shown above. Acclimate your floor as close to the installation area as possible, for 1 to 3 days in normal living conditions.


CONTROL ENVIRONNEMENT



20-80% rH

Engineered flooring can be used in areas ranging from 20% to 80% relative humidity.

EXPANSION GAPS



Leave at least 1/2" expansion spaces between flooring and ALL vertical objects (walls, cabinets, pipes, etc.) **Large flooring runs may require additional expansion space.** Use transition moldings between rooms and doorways. Undercut door jambs and casings to provide adequate expansion space. Do not screw or nail cabinetry or other permanent fixtures to a floating floor